





XIAOMI

Android 11 - MIUI 12


# HOW TO SET DURATION OF ALWAYS ON DISPLAY




Tap on **Settings**




# Tap on Always-on display & Lock screen



# Tap on Always-on display



# Tap on Display items



# Choose an option

Notice: The given options are device dependent

Done!