

XIAOMI

Android 11 - MIUI 12


HOW TO TURN ON/OFF SHARE KEYBOARD USAGE STATISTICS




Tap on **Settings**




Tap on Additional settings




Tap on Languages & input




Tap on
Manage keyboards



Tap on **Settings**



Tap on **Advanced**



Turn On/Off

Share usage statistics

Done!