

XIAOMI

Android 11 - MIUI 12


HOW TO SET UP TEXT-TO-SPECH OUTPUT






Tap on Settings






Tap on Additional settings






Tap on Accessibility






Tap on Vision





Tap on Text-to-speech output





Change the Language or swipe to set the Speech rate / Pitch



Done.

