


XIAOMI


Android 11 - MIUI 12

HOW TO TURN ON/OFF ULTRA BATTERY SAVER







Tap on **Settings**



Tap on Battery & performance



Enable Ultra battery saver



Tap on **OK**

Done!