


XIAOMI

Android 11 - MIUI 12


HOW TO TURN ON/OFF VIBRATION FOR INCOMING CALLS



Tap on **Settings**



Tap on Sound & vibration



Turn On/Off Vibrate for calls

Done!