


XIAOMI

Android 11 - MIUI 12


HOW TO UNMOUNT SD CARD




Tap on **Settings**



Tap on
About phone



Tap on Storage



Tap on
Unmount SD card

Done!