

SAMSUNG

Android 11 - One UI 3

HOW TO TURN ON/OFF CAMERA QUICK LAUNCH

techbone



Tap on Settings

techbone



Tap on Advanced features

techbone



Tap on Side key

techbone



Choose Quick launch camera

techbone

Done!

techbone